






INSTALLATION GUIDE

STANDING SEAM


Standing Seam Ridge Cap Detail




Standing Seam Rake Detail





Standing Seam Rake Trim



Fascia / Soffit Detail




Standing Seam One-Slope Cap








Standing Seam Endwall Flashing Detail




Standing Seam Sidewall Flashing Detail





Standing Seam Transition Trim Detail





Standing Seam Valley Trim Detail




Standing Seam Valley Trim



Hemming Details



Slide the panel onto the roof, clipping it onto the previous panel and all the way up against the drip edge.



Use the tongs to clamp the folded over hem tightly to the drip edge.
Fold over the extra tab on the rib, trimming with a snips to ensure an exact fit.


Standing Seam Trims




Ridge Cap (SSRCP)




One-Slope Ridge Cap (SS1RCP)




Rake Trim (SSR)




Z-Trim (SSZ)



Drip Edge (SSDE)




Endwall (SSEW)




Valley Trim (SSVT)



Sidewall (SSSW)



Transition Flashing (SSTF)



Coil Slitting and Recoiling

We now offer custom slitting and recoiling. Get the exact coil you need, when you need it. Available in any of our colors or gauges, or bring your own!

Packaging and slit fees may apply. Please contact our sales team for more information.

